Answer B is correct

The primary seal leaks internally, and the secondary seal leaks externally. A leaking secondary seal will result in fluid dripping from the clutch master onto the driver’s side floor panel.