



# **Xclusive** Multi-Purpose **Convex Mirrors**



## **INSTALLING THE MULTI-PURPOSE CONVEX MIRROR**

1. Locate and clean the surface on the 4 corners of the mirror back where it will be mounted. Clean the surface with an alcohol prep pad then **Wipe the Surface Dry with a Clean Paper Towel**.



*Alcohol Prep Pads are Included in the Kit*



**Clean with Alcohol**



**Dry with Paper Towel**

2. Remove the carrier paper from the double adhesive (included in the kit) and **press it FIRMLY into place** on the 4 back corners of the mirror that you have **cleaned and dried** with the alcohol prep.



3. Locate, clean, and dry the area of the surface where you have determined the mirror to be placed.



4. Remove the protective film from the mirror surface; you will see a label on the film marked **PEEL**. Press the Convex Mirror onto the chosen area making sure it is positioned the way you want. Press the Convex Mirror **FIRMLY** into place to make sure the adhesive has made a good bond.



*Call your Customer Service Representative for additional information*

## **Se-Kure Domes & Mirrors**

1139 Haines Blvd. • Sturgis, MI 49091 • 1-800-253-2064 • (269) 651-9351 • Fax: (269) 651-1467  
www.domesandmirrors.com • email: info@domesandmirrors.com