



**Create an Elegant In-The-Hoop Hot Pad
with IQ Designer on the Solaris Vision
Follow along with the video on our App dated 12/13/22**

How I figured out what size I wanted to make:

Hoop size is 10.5" wide x 16" Tall

Maximum hot pad width is 10"

Maximum hot pad height is 15.5"

I want a 1 ½" border all around:

15.5" - 3" = 12.5" inner border height

10" - 3" = 7" inner border width

First we need to baste down the batting and trim away the excess so the seam allowance is not so bulky.

1. IQ Designer
2. Shapes
3. Circle
4. OK
5. Size
6. 15.5" x 10"
7. Ok
8. Line Properties
9. Red
10. Straight Stitch
11. OK
12. Line Bucket
13. Touch the line to turn it red
14. Next
15. Memory
16. Save on machine
17. Set
18. OK
19. Memory Save on machine

20. Add
21. IQ Designer Start with placement line and fill stitching
22. Pocket with arrow pointing out
23. Large Oval
24. OK
25. Size
26. 3" Smaller 12.5" x 7"
27. OK
28. Line Properties
29. Straight Stitch
30. Purple
31. OK
32. Line Bucket
33. Touch the line to turn it purple
34. Memory
35. Save on the machine (You are only saving this oval shape)
36. Next
37. Set
38. OK
39. Memory
40. Save on machine
41. Add
42. IQ Designer
43. Pocket with the arrow pointing out
44. Purple Oval
45. OK
46. Line Properties
47. No Sew
48. OK
49. Line Bucket
50. Touch the line to make it no sew.
51. Fill Properties
52. Circle Fill
53. Select
54. Choose your favorite fill
55. OK
56. Green
57. OK
58. Fill Bucket
59. Touch inside the oval to add the fill stitch
60. Next
61. Memory
62. Save on machine
63. Set
64. OK

65. Add
66. IQ Designer
67. Pocket with arrow pointing out
68. Purple Oval Placement Line
69. OK
70. Line Properties
71. Straight Stitch
72. Pink
73. OK
74. Line Bucket
75. Touch the line to turn it pink
76. Next
77. Memory
78. Save on the machine
79. Set
80. OK
81. Add Candlewicking
82. IQ Designer
83. Pocket with the arrow pointing out
84. Pink Oval
85. OK
86. Line Properties
87. Candlewicking
88. Blue
89. OK
90. Line Bucket
91. Touch the line to turn it blue
92. Next
93. Size 0.160" to 0.220
94. OK
95. Spacing 0.040 down to 0.028
96. OK
97. Memory save on machine
98. Set
99. OK
100. Add Outer Border Stitch
101. IQ Designer
102. Pocket with arrow pointing out
103. Big Oval The first one you saved (Press size to make sure you chose
104. the 15.5" x 10")
105. Line Properties
106. Straight Stitch
107. Orange
108. OK
109. Line Bucket

- 110. Touch the line to turn it orange
- 111. Next
- 112. Set
- 113. OK
- 114. Embroidery
- 115. Memory
- 116. Save on the machine

Step 1:

Hoop No-Show Stabilizer
Lay batting on top
Stitch down batting
Trim off excess

Step 2:

Lay Solid Fabric on top
Stitch inner oval placement line

Step 3: Stitch BEAUTIFUL Fancy Fill

Trim off excess fabric leaving 1/4"

Step 4:

Lay at least an 11" x 16" piece of fabric on top
Stitch the inner oval with straight stitch.

Step 5: Trim away fabric from center

Stitch the Candlewicking Stitch

Step 6:

With right sides together, lay two pieces of fabric (folded in half) on top,
overlapping at least 3/4"

Stitch

Trim off excess fabric leaving 1/4" seam allowance.

Turn and Press

Seal opening shut with 1/2" Steam a Seam 2