

Battery / Gas Tank Regulations:

To insure the safety of everyone in our facility, the following are the basic requirements for any vehicle with a battery and a gas tank that is displayed at the Lansing Center, and are the responsibility of the client/owner:

1. The client /owner must disconnect vehicle battery.
2. Gas tank must have 1/8 of a tank of gas and no more than 5 gallons.
3. Gas tank must have a locking gas cap.
4. A drop cloth or plastic sheeting must be placed under the engine.
5. Vehicle is to be dried as much as possible before entering the building.
6. If the vehicle is place on a carpeted area, additional carpet squares must be placed under the wheels.
7. A set of keys must be left with security, with the name of contact person and cell phone number, available 24 hours a day, for each day the vehicle is at the Lansing Center.
8. Vehicle location and set-up times must be approved and arranged through the Event Coordinator.
9. Post-event, vehicle must be removed promptly, within the contracted time.