

G Repair, Replace, Install		4.0		Standard	Member	Saving
A. Accumulator		D. In Warranty Compressor	G. Relocate Condensing Unit	\$1,820.00	\$1,274.00	\$546.00
B. Back Flow Preventor		E. In Warranty Condensor Coil	H. Reversing Valve			
C. In Warranty Evaporator		F. In Warranty Heat Exchanger	I. Variable Speed Inducer Motor			
F Repair, Replace, Install		2.0		Standard	Member	Saving
A. Blwr Housing, Whl, Shaft & Bmgs		G. Level 3 Wiring	M. Variable Speed Module Only	\$1,034.00	\$723.80	\$310.20
B. Clean Restricted Heat Exchanger		H. Primary Circuit Board	N. Warranty Parts Labor Only - (L-E)			
C. Electric Heat Package		I. Pump Down, Vacuum, Recharge	O. Hi/Lo Refrigerant Switch			
D. Flueliner		J. Ref Recovery, Recharge & Drier Replace	P. Zone Damper Board			
E. Gas Valve 2 Stage or Special		K. TXV Expansion Valve	Q. Variable Speed Inducer Motor			
F. Inducer Fan Motor Assembly		L. Fan Control Center				
E Repair, Replace, Install		1.25		Standard	Member	Saving
A. Collector Box		F. Fan Control Center	L. Secondary Circuit Board	\$642.00	\$449.40	\$192.60
B. Condensate Pump w/ tubing		G. Flue Pipe (furnace to chimney base)	M. Shaft and Bearings			
C. Defrost Circuit Board		H. Gas Burners (Complete Set)	N. Relocate T-Stat			
D. Disconnect Box & Fuses		I. Gas Valve	O. Warranty Parts Labor Only - (L-D)			
E. Dual Fuel Prog. T-Stat (LTW)		J. Level 2 Wiring	P. Warranty Parts Labor - (F)			
		K. Motor	Q. Severe Burnout Return Trip			
D Repair, Replace, Install		1.0		Standard	Member	Saving
A. 3 WirePilot		K. Install Thermistor	U. Suction Line Drier	\$457.00	\$319.90	\$137.10
B. Blower Wheel Only		L. Level 1 Wiring	V. Time Delay Relay			
C. Defrost Thermostat		M. Limit Switch	W. Warranty Labor Only - (L-C)			
D. Condensor Fan Blade		N. Locate Short Level 2	AA. Non-Specific Minor Repair - (L-C)			
E. Crank Case Heater		O. Pilot Assembly	BB. Warranty Labor (E.)			
F. Defrost Thermostat		P. Programmable T-Stat (LTW)	CC. Damper Motor			
G. Defrost Thermostat		Q. Pressure Switch				
H. Electronic Leak-Search 2		R. Replace Breaker				
I. Gas Pipe (up to 6' and fittings)		S. Sequencer 3 Stack				
J. Humidifier Solenoid		T. Service Valve				
C Repair, Replace, Install		0.75		Standard	Member	Saving
A. Dual Start Assist		D. Warranty Part Labor Only	G. Ref. Leak Seal	\$340.00	\$238.00	\$102.00
B. Compressor Starter		E. UV Lightbulb	H. Transformer			
C. Hard Start Assist Kit		F. Warranty Parts - Labor for D	I. Warranty Labor (D)			
B Repair, Replace, Install		0.50		Standard	Member	Saving
A. Access Plenum		L. Clean heat Exchanger	V. Locate Short Level 1	\$241.00	\$168.70	\$72.30
B. Acid Test & Neutralizer		M. Clean Ignition Components	W. Motor Bracket			
C. Start Assist - Single		N. Compressor Cool Down	X. Relay			
D. Warranty Labor C		O. Condensate Trap	Y. Sadle Valve			
E. Clean Blower Assembly		P. De-Ice In/Outdoor Coil	Z. Sequencer Up to 2-Stack			
F. Clean Condensate Trap		Q. Door Switch	AA. Shipping & Handling (Overnight)			
G. Clean Condensor Coil		R. Flame Sensor	BB. Sound Bracket			
H. Clean Drain Line		S. Hot Surface	CC. Thermocouple			
I. Clean Evap. Coil		T. Humidistat	DD. Warranty Part - Labor Only - (L-B)			
J. Clean Flue Pipe to base of Chimney		U. Level T-Stat and Adjust Anticipator	EE. Non-Specific Minor Repair - (L-B)			
K. Clean Furnace Burners						
Precision Safety Inspection Furnace, Air Conditioner						
A Repair, Replace, Install		0.40		Standard	Member	Saving
A. Align Coil Fins		E. Fan Belt & Adjust Replace	I. Reset and Check Breaker	\$142.00	\$99.40	\$42.60
B. Clean Flame Sensor & Test		F. Fuse Links Replace	J. Schrader Valve Core			
C. Clean Permanent Filter		G. Fuses Replaced (2)	K. Shipping and Handling			
D. Clean Pilot Assembly		H. Ionizing Wires Replace	L. Warranty Part - Labor Only - (L-A)			
			M. Warranty Labor			