

eKEY® App Compatible Phones and Tablets

The Supra® eKEY® application is rigorously tested on popular models of smartphones and tablets to determine its compatibility with Android™, Apple®, and BlackBerry® mobile devices. This list shows some of the specific devices tested. Check with your MLS or Board regarding which keyboxes are currently used.

Android	Apple	BlackBerry																										
<p>Requirements:</p> <ul style="list-style-type: none">• Phones or tablets with OS 2.1 or newer, except devices running Google Project Fi• A cellular data plan• The current eKEY application downloaded to the Android phone or tablet <p>A Supra® eKEY Fob is not required to open the iBox BT LE or iBox BT keybox. A fob is required to open the classic iBox keybox.</p>  <p>Supra eKEY Fob</p> <p>Some Example Devices:</p> <table border="1"><tr><td>BlackBerry®</td><td>Priv™</td></tr><tr><td>Google</td><td>Nexus™ 7, Nexus One, Nexus S</td></tr><tr><td>HTC™</td><td>Aria™, Desire, Eris, EVO™ 4G & 3D, Hero™, Incredible 2, Incredible, Sense, Thunderbolt™, Touch 2, and Wildfire™</td></tr><tr><td>LG®</td><td>Enlighten™, Intuition™, Optimus™, Revolution™, Thrill™, and Vortex™</td></tr><tr><td>Motorola™</td><td>Atrix 2, Bionic, Droid 2, Droid X, Razr, and Razr M</td></tr><tr><td>Samsung®</td><td>Charge, Epic™, Galaxy S™7, S6, S5, S4, S3, S2, & S, Galaxy Note™ 4, 3, & 2, and Moment</td></tr></table>	BlackBerry®	Priv™	Google	Nexus™ 7, Nexus One, Nexus S	HTC™	Aria™, Desire, Eris, EVO™ 4G & 3D, Hero™, Incredible 2, Incredible, Sense, Thunderbolt™, Touch 2, and Wildfire™	LG®	Enlighten™, Intuition™, Optimus™, Revolution™, Thrill™, and Vortex™	Motorola™	Atrix 2, Bionic, Droid 2, Droid X, Razr, and Razr M	Samsung®	Charge, Epic™, Galaxy S™7, S6, S5, S4, S3, S2, & S, Galaxy Note™ 4, 3, & 2, and Moment	<p>Requirements:</p> <ul style="list-style-type: none">• Phones or tablets with iOS 6 or newer• A cellular data plan• The current eKEY application downloaded to the Apple phone or tablet <p>Access the iBox BT LE only, using Bluetooth® with an iPhone® (4s and newer), iPad® (4th & 3rd Generations), or iPad Mini.</p> <p>Older Apple models (iPhone 4, 3GS, and iPad 2) require a Supra eKEY Fob to open the iBox BT LE, iBox BT, or iBox keyboxes.</p>  <p>Supra eKEY Fob</p> <p>Some Example Devices:</p> <table border="1"><tr><td colspan="2">Open an iBox BT LE keybox (without a Supra Fob):</td></tr><tr><td>iPhone®</td><td>7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, and 4s</td></tr><tr><td>iPad®</td><td>iPad Mini, iPad Pro, 4th Gen., 3rd Gen.</td></tr><tr><td colspan="2">Open an iBox BT or classic iBox with a Supra Fob and:</td></tr><tr><td>iPhone®</td><td>7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, 4s, 4, and 3GS</td></tr><tr><td>iPad®</td><td>iPad Mini, iPad Pro, 4th Gen., 3rd Gen., and 2G</td></tr></table>	Open an iBox BT LE keybox (without a Supra Fob):		iPhone®	7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, and 4s	iPad®	iPad Mini, iPad Pro, 4 th Gen., 3 rd Gen.	Open an iBox BT or classic iBox with a Supra Fob and:		iPhone®	7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, 4s, 4, and 3GS	iPad®	iPad Mini, iPad Pro, 4 th Gen., 3 rd Gen., and 2G	<p>Requirements:</p> <ul style="list-style-type: none">• Phones or tablets with OS 5 or newer, except BlackBerry 10• A cellular data plan• The current eKEY application downloaded to the BlackBerry phone <p>A Supra® eKEY Fob is not required to open the iBox BT LE or iBox BT keybox. A fob is required to open the classic iBox keybox.</p>  <p>Supra eKEY Fob</p> <p>Some Example Devices:</p> <table border="1"><tr><td>BlackBerry</td><td>8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™</td></tr></table>	BlackBerry	8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™
BlackBerry®	Priv™																											
Google	Nexus™ 7, Nexus One, Nexus S																											
HTC™	Aria™, Desire, Eris, EVO™ 4G & 3D, Hero™, Incredible 2, Incredible, Sense, Thunderbolt™, Touch 2, and Wildfire™																											
LG®	Enlighten™, Intuition™, Optimus™, Revolution™, Thrill™, and Vortex™																											
Motorola™	Atrix 2, Bionic, Droid 2, Droid X, Razr, and Razr M																											
Samsung®	Charge, Epic™, Galaxy S™7, S6, S5, S4, S3, S2, & S, Galaxy Note™ 4, 3, & 2, and Moment																											
Open an iBox BT LE keybox (without a Supra Fob):																												
iPhone®	7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, and 4s																											
iPad®	iPad Mini, iPad Pro, 4 th Gen., 3 rd Gen.																											
Open an iBox BT or classic iBox with a Supra Fob and:																												
iPhone®	7 Plus, 7, 6s Plus, 6s, 6 Plus, 6, 5s, 5c, 5, 4s, 4, and 3GS																											
iPad®	iPad Mini, iPad Pro, 4 th Gen., 3 rd Gen., and 2G																											
BlackBerry	8800 series Bold™ Touch Curve™ Pearl™/Pearl Flip Storm™ Torch™ Tour™																											

Contact Support at 1-877-699-6787 if you have a question about a specific phone or tablet.



www.supraekey.com

© 2017 United Technologies Corporation. All rights reserved. Supra is a part of UTC Climate, Controls & Security and a unit of United Technologies Corporation. Supra and eKEY are registered trademarks of United Technologies Corporation. Other brand and product names are or may be the trademarks of, and are used to identify products or services of, their respective owners. User experience may vary depending on the device manufacturer, cellular reception, data plan, and other variables beyond Supra's control.