




Answer C is correct

Mode door actuators will click as the gears wear and become faulty. Most of these actuators require a calibration procedure after replacement.