



## TRL TIP #1

### **What is a Technology Readiness Level and why does it matter to you?**

TRLs are a measurement system to assess the maturity level of a particular technology. The system was developed by NASA and has been used for many years by the Department of Defense and contracting agencies as a way to determine if a product is ready for the market.

If you don't work with contracting agencies, you might be tempted to say, "Why do I need to know that?" Simple. Granting agencies like NIH and NSF are increasingly using the same type of scales, and if your product will have applications with the military or NASA, you'll need to be familiar with them.

Here's a basic look at the nine types of TRLs. Future articles will examine the individual types more closely.

#### **TRL 1: Basic Principles Observed and Reported**

Lowest level of technology readiness. Scientific research begins to be translated into applied research and development. Examples might include paper studies of a technology's basic properties.

## **TRL 2: Technology Concept and/or Application Formulated**

Invention begins. Once basic principles are observed, practical applications can be invented. Applications are speculative and there may be no proof or detailed analysis to support the assumptions. Examples are limited to analytic studies.

## **TRL 3: Analytical and Experimental Critical Function and/or Characteristic Proof-of-Concept**

Active research and development is initiated. This includes analytical studies and laboratory studies to physically validate analytical predictions of separate elements of the technology. Examples include components that are not yet integrated or representative.

## **TRL 4: Component and/or Breadboard Validation in a Laboratory Environment**

Basic technological components are integrated to establish that they will work together. This is relatively “low fidelity” compared to the eventual system. Examples include integration of “ad hoc” hardware in the laboratory.

## **TRL 5: Component and/or Breadboard Validation in a Relevant Environment**

Fidelity of breadboard technology increases significantly. The basic technological components are integrated with reasonably realistic supporting elements so it can be tested in a simulated environment. Examples include “high fidelity” laboratory integration of components.

## **TRL 6: System/Subsystem Model or Prototype Demonstration in a Relevant Environment**

Representative model or prototype system, which is well beyond that of TRL 5, is tested in a relevant environment. Represents a major step up in a technology’s demonstrated readiness. Examples include testing a prototype in a high- fidelity laboratory environment or in simulated operational environment.

### **TRL 7: System Prototype Demonstration in an Operational Environment**

Prototype near, or at, planned operational system. Represents a major step up from TRL 6, requiring demonstration of an actual system prototype in an operational environment such as an aircraft, vehicle, or space. Examples include testing the prototype in a test bed aircraft.

### **TRL 8: Actual System Completed and Qualified through Test and Demonstration**

Technology has been proven to work in its final form and under expected conditions. In almost all cases, this TRL represents the end of true system development. Examples include developmental test and evaluation of the system in its intended weapon system to determine if it meets design specifications.

### **TRL 9: Actual System Proven through Successful Mission Operations**

Actual application of the technology in its final form and under mission conditions, such as those encountered in operational test and evaluation. Examples include using the system under operational mission conditions.

If you need to talk with someone now about TRLs, please contact us at [info@bbcetc.com](mailto:info@bbcetc.com) or [click here](#) to fill out a company assessment form.