



JARCHEM INDUSTRIES, INC.

An ISO 9001:2008 Company

414 Wilson Avenue

Newark, NJ 07105

Tel# (973) 344-0600

Fax# (973) 344-5743

E-Mail: info@jarchem.com

Website: www.jarchem.com

FORMULATION

Jarchem™ Double Black Diamond Firming Clay Mask Formula No. AK01046

PHASE	INGREDIENTS	INCI NAME	%	SUPPLIER
A	Water	Water	59.86	
	Magnesium Aluminum Silicate	Magnesium Aluminum Silicate	4.5	Vanderbilt
B	Zemea™	Propanediol	2.5	Dupont Tate & Lyle Bioproducts
	Glycerin	Glycerin	2.5	
	Xanthan Gum	Xanthan Gum	0.24	
C	Jarxotic™ BLACK DIAMOND CLAY	Illite (and) Quartz (and) Kaolin	29.4	Jarchem
D	Euxyl™ K940	Phenoxyethanol (and) Benzyl Alcohol (and) Ethylhexylglycerin	1.0	Schülke

Procedure:

1. Add water to main vessel and heat to 65-70°C. Sprinkle in Magnesium Aluminum Silicate and mix for 15 minutes.
2. In a separate vessel, mix Phase B.
3. Remove Phase A from heat, and add Phase B to Phase A while mixing.
4. Add Phase C ingredients one at a time while mixing.
5. Add Phase D and mix.

Effective: 03/21/19

The above supersedes any provision in your forms, letters, and papers. JARCHEM INDUSTRIES makes no warranty, whether expressed or implied, including warranties of merchantability or fitness for a particular purpose, for the chemicals it sells. Under no circumstances shall JARCHEM INDUSTRIES be liable for incidental, consequential, or other damages from alleged negligence, breach of warranty, strict liability, or any other theory arising from the use or handling of the chemicals it sells. The sole liability, if any, of JARCHEM INDUSTRIES for any claims arising out of the manufacture, use, or sale of its chemicals shall be for the return of the buyer's purchase price. The information contained herein is to our best knowledge true and accurate. Recommendations and suggestions are made without guarantee of favorable results since conditions of use are beyond our control. These data shall not be construed as a recommendation to use any product in conflict with existing patents covering any material or use.