

D.1 - CAMERA EQUIPMENT DISINFECTION



Effective Date – June 8, 2020

Equipment	Disinfection Methods	Personal Protective Equipment (PPE)	Procedures
Camera Body	99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. Eye cups and viewfinders get extra attention, clean with isopropyl alcohol. Do not spray cleaners directly onto equipment.
Lenses	100% Ethyl Alcohol + 99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. Optical surfaces cleaned with 100% ethyl alcohol. Do not spray cleaners directly onto equipment.
Electronic Camera Accessories	99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. Do not spray cleaners directly onto equipment.
Mechanical Camera Accessories	99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. High touch areas get extra attention with isopropyl alcohol. Do not spray cleaners directly onto equipment.
Camera Support (Heads / Sticks / Handle Grips)	99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. All handheld items and panhandles to receive extra attention with isopropyl alcohol.
Camera Equipment Cases and Carts	99% Isopropyl Alcohol + Clorox GreenWorks AP Cleaner	Nitrile Gloves	Pre-clean with isopropyl alcohol, general clean with AP cleaner. Latches and handles to receive extra attention with isopropyl alcohol.

If you are responding to an extraordinary circumstance (e.g., cruise ship, hospitals or other medical facilities, etc.) where you are unsure of the proper protocol, please contact Whites SH&E for additional guidance at WhitesSafety@whites.com.